




SEAT

PREPARATION

023QS–01

Recomended Tools

	09042–00010	Torx Socket T30	FRONT SEAT ASSY RH (POWER SEAT TYPE) FRONT SEAT ASSY RH (MANUAL SEAT TYPE)
	09042–00020	Torx Socket T40	REAR NO.1 SEAT ASSY RH REAR NO.1 SEAT ASSY LH
	09042–00050	Torx Socket T45	REAR NO.1 SEAT ASSY RH REAR NO.1 SEAT ASSY LH
	09082–00040	TOYOTA Electrical Tester	FRONT POWER SEAT CONTROL SYSTEM
	09200–00010	Engine Adjust Kit	FRONT SEAT ASSY RH (POWER SEAT TYPE) FRONT SEAT ASSY RH (MANUAL SEAT TYPE)

Equipment

Clipremover	
Hog ring	
Hog ring pliers	
Tape	To avoid surface damage
Torque wrench	
Torx socket wrench (T55)	