0320A–01

TORQUE SPECIFICATION

Part Tightened	N·m	kgf·cm	ft·lbf
Fuel delivery pipe sub–assy x Intake manifold	10	102	7
Fuel delivery pipe No. 2 x Intake manifold	10	102	7
Fuel pipe No. 2 union bolt x Fuel delivery pipe No. 2	33	331	24
Fuel pressure pulsation damper assy x Fuel delivery pipe sub–assy	33	331	24
Fuel pipe sub–assy No. 1 x Intake manifold	20	199	14
Surge tank stay No. 2 x Intake air surge tank	20	199	14
Surge tank stay No. 2 x Cylinder head	20	199	14
Surge tank stay No. 1 x Intake air surge tank	20	199	14
Surge tank stay No. 1 x Cylinder head	20	199	14
Engine hunger No. 1 x Intake air surge tank	20	199	14
Engine hunger No. 1 x Cylinder head	20	199	14
Pressure feed tube assy x Engine hunger No. 1	7.8	80	69 in.·lbf
Intake air surge tank x Intake manifold	28	286	21
Emission control valve set x Emission control valve bracket	8.0	82	71 in.·lbf
Fuel tank band sub–assy No. 1 RH x Body	39	400	29
Fuel tank band sub–assy No. 1 LH x Body	39	400	29
Fuel tank protector lower center x Fuel tank assy	5.5	56	49 in.·lbf
Packing brake cable assy No. 2 x Body	5.4	55	48 in.·lbf
Exhaust pipe assy center x Exhaust pipe assy front	48	490	35
Exhaust pipe assy center x Exhaust pipe assy tail	48	490	35