

05D6N–02

LOCATION




Combination Meter Assy:
● CHK Engine Lamp
ECM
R/B No.1:
● Circuit Opening Relay
Instrument Panel J/B:
● IGN Fuse
● STOP Fuse
Y
A91278