DTC C1201/51 ENGINE CONTROL SYSTEM MALFUNCTION

CIRCUIT DESCRIPTION

If trouble occurs in the engine control system, the skid control ECU prohibits TRAC and VSC control.

DTC No.	DTC Detecting Condition	Trouble Area
C1201/51	At the engine speed of 500 rpm, a trouble signal in the engine control system continues for 5 secs. or more.	Engine control system

INSPECTION PROCEDURE

1	CHECK DTC FOR ENGINE

(a) Check if the normal code is recorded for SFI system.

A	Normal System Code
B	Trouble Code

B → REPAIR ENGINE CONTROL SYSTEM ACCORDING TO DTC OUTPUT

A

REPLACE ECM