05JPK–01

# CHECK MODE PROCEDURE

**1. SIGNAL CHECK (CHECK MODE) (USING HAND–HELD TESTER)**

(a) Connect the hand–held tester to the DLC3.

(b) Turn the ignition switch to the ON position.

(c) Select the ”SIGNAL CHECK”, and proceed checking with the hand–held tester.