SOUND QUALITY IS BAD IN ALL MODES (VOLUME IS TOO LOW)

INSPECTION PROCEDURE

1	ADJUST SOUND QUALITY

(a) Adjust the sound quality.
(1) Operate the radio receiver assy to adjust the sound quality.
OK: Malfunction disappears.

OK → BAD SOUND QUALITY

NG

2	COMPARE IT WITH ANOTHER VEHICLE OF SAME MODEL

(a) Compare it with another vehicle of the same model.
(1) Compare it with the vehicle of the same type which does not have a trouble to see if there is any difference in the sound quality.
OK: No difference is found.

OK → SETTING

NG

REPLACE RADIO RECEIVER ASSY (SEE PAGE 67–5)