
CURSOR OR MAP ROTATES WHEN VEHICLE IS STOPPED

INSPECTION PROCEDURE

1	CHECK CONDITION



(a) Check with the customer if the vehicle has been turned by a turntable at parking.

OK: The vehicle has not been turned by a turntable.

HINT:

If the ignition switch is turned to the ACC or ON position while the vehicle is being turned by a turntable, the system may store the angular velocity at this time. For this reason, the vehicle position cursor could deviate.

NG → **TURN IGNITION SWITCH TO ON POSITION WHEN VEHICLE IS COMPLETELY STOPPED**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05–880)