
ROUTE CANNOT BE CALCULATED

INSPECTION PROCEDURE

1	CHECK THE MAP DISC



(a) Check that the map disc is not deformed or cracked.
OK: No deformations or cracks appear on the map disc.

NG → **REPLACE THE MAP DISC**

OK

2	SET DESTINATION

(a) Set another destination and check if the system can calculate the route correctly.
OK: Route can be correctly calculated.

OK → **NORMAL OPERATION**

NG

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE
(SEE PAGE 05–880)