POWER DOOR LOCK CONTROL SYSTEM

05JYJ–01

PRECAUTION

1. NOTICES OF REMOVAL AND INSTALLATION OPERATIONS

(a) Before performing operations related to the door lock and door lock cylinder, be sure to disconnect the battery terminal or the connector of the window regulator motor.

CAUTION:

If the operation is performed with the connectors connected, the door control switch inside the door lock might unexpectedly actuate, which may result in injury.