05JYF–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Only wireless control function is inoperative	1. Transmitter battery 2. Transmitter sub–assy module set door control 3. Door control receiver 4. DOME fuse 5. Body ECU 6. Unlock warning switch	05–1050
No answer–back (Hazard warning lamp and wireless door lock buzzer)	1. Wireless door lock buzzer 2. Lighting system 3. Wire harness 4. Multiplex network body ECU	05–1050