DTC B2793 TRANSPONDER CHIP MALFUNCTION

CIRCUIT DESCRIPTION

This DTC is output when: 1) during key code registration, there was a key malfunction; or 2) the key code was unable to be registered properly. Follow the inspection procedure below.

DTC No.	DTC Detection Condition	Trouble Area
B2793	Transponder chip malfunction	Key

INSPECTION PROCEDURE

1	RE–REGISTER KEY

(a) Delete the DTC.
(b) Re–register the key, and check that the engine starts with the key.
OK: Engine starts.

NG → **REPLACE KEY**

OK

NORMAL