
FUEL PUMP ASSY (3MZ–FE)

COMPONENTS

11132–01

w/ Rear No. 2 Seat




N·m (kgf·cm, ft·lbf) : Specified torque

P

A92780


w/o Rear No. 2 Seat



N·m (kgf·cm, ft·lbf) : Specified torque


P

A92780



◆ Non–reusable part

A92785


Fuel Suction Plate Sub–assy
Fuel Pump Harness
◆ O–Ring
Fuel Pump Spacer
Fuel Pump
Clip
◆ O–Ring
Fuel Pressure Regulator Assy
Fuel Tube Joint No. 1
◆ O–Ring
◆ O–Ring
Fuel Filter Assy
◆ Clip
Fuel Suction Support No. 1
Fuel Sender Gage Assy
◆ Non–reusable part
Y
A81632