PARKING BRAKE SYSTEM

PROBLEM SYMPTOMS TABLE

330CV–03

Use the table below to help find the cause of the problem. The numbers indicate the priority of the possible cause of the problem. Check each part in order. If necessary, replace these parts.

Symptom	Suspected Area	See page
Brake drag	1. Parking brake pedal travel (Out of adjustment)	33–2
	2. Parking brake wire (Sticking)	33–10 33–13
	3. Parking brake shoe clearance (Out of adjustment)	33–17
	4. Parking brake shoe lining (Cracked or distorted)	33–17
	5. Tension or return spring (Damaged)	33–17