
AIR CONDITIONING RADIATOR ASSY

COMPONENTS


551C2–01



N·m (kgf·cm, ft·lbf) : Specified torque
⬅ Compressor oil ND–OIL 8 or equivalent
◆ Non–reusable parts

P

I39667


Wiring Air Conditioning Harness Sub–assy
Clamp
Wiring Air Conditioning Harness Sub–assy No.2
Clamp
Cooler Expansion Valve
◆ O–ring
◆ O–ring
Air Conditioning Tube Assy
Heater Radiator Unit Sub–assy
Cooler Evaporator Sub–assy No.1
5.4 (55, 48 in.·lbf)
Air Outlet Control Servomotor (Mode Damper Servo Sub–assy)
Evaporator Temperature Sensor (Cooler Thermistor No.1)
Air Mix Control Servomotor (Air Mix Damper Servo Sub–assy)
Air Duct No.1
Blower Motor Control
w/ Navigation System:
Air Duct No.2
Air Conditioner Amplifier Assy
N·m (kgf·cm, ft·lbf) : Specified torque
Compressor oil ND–OIL 8 or equivalent
◆ Non–reusable parts
P
I39668