

67176–01


COMPONENTS



P

I38965


Antenna Cord
Sub–Assy No.2
Navigation Antenna Assy
Power Outlet Socket Assy
Power Outlet Socket Cover
Cigarette Lighter Assy
Cigarette Lighter Cover
Power Outlet Socket Assy CTR
Power Outlet Socket
Cover CTR
P
I38966


W/Holder Antenna Assy
Front No.2 Speaker Assy
Front No.1 Speaker Assy
Rear Speaker Assy
Navigation ECU
Disc Player Bracket No.2
Disc Player Bracket
Power Outlet Socket Assy RR
Power Outlet Socket
Cover RR
P
I38967