NAVIGATION ECU


REPLACEMENT

67179–01


HINT:

- COMPONENTS: See page 67–2
- Installation is in the reverse order of removal.


1. **REMOVE GLOVE COMPARTMENT DOOR ASSY** (SEE PAGE 71–9)
2. **REMOVE INSTRUMENT PANEL FINISH PANEL LOWER NO.2** (SEE PAGE 71–9)



3. **REMOVE NAVIGATION ECU W/BRACKET**
   (a) Disconnect the connector.
   (b) Remove the 3 nuts and the navigation ECU w/ bracket.



4. **REMOVE DISC PLAYER BRACKET**
   (a) Remove the 2 screws and the disc player bracket.



5. **REMOVE DISC PLAYER BRACKET NO.2**
   (a) Remove the 2 screws and the disc player bracket No.2.

6. **REMOVE NAVIGATION ECU**
7. **INSTALL NAVIGATION ECU**

HINT:

Perform the screen noise automatic adjustment when screen noise occurs (see page 05–900).