





STARTING & CHARGING



023NK–01



PREPARATION

SST

	09820–63010	Alternator Pulley Set Nut Wrench Set	GENERATOR ASSY(3MZ–FE)
	(09820–06010)	Alternator Rotor Shaft Wrench	GENERATOR ASSY(3MZ–FE)
	(09820–06020)	Alternator Pulley Set Nut 22 mm Wrench	GENERATOR ASSY(3MZ–FE)
	09820–00021	Alternator Rear Bearing Puller	GENERATOR ASSY(3MZ–FE)
	09820–00031	Alternator Rotor Rear Bearing Replacer	GENERATOR ASSY(3MZ–FE)
	09285–76010	Injection Pump Camshaft Bearing Cone Replacer	GENERATOR ASSY(3MZ–FE)
	09950–60010	Replacer Set	GENERATOR ASSY(3MZ–FE)
	(09951–00250)	Replacer 25	GENERATOR ASSY(3MZ–FE)
	09950–70010	Handle Set	GENERATOR ASSY(3MZ–FE)
	(09951–07100)	Handle 100	GENERATOR ASSY(3MZ–FE)

Recomended Tools

	09082–00040	TOYOTA Electrical Tester	STARTER ASSY(3MZ–FE) GENERATOR ASSY(3MZ–FE)
	(09083–00150)	Test Lead Set	STARTER ASSY(3MZ–FE) GENERATOR ASSY(3MZ–FE)

	09904–00010	Expander Set	STARTER ASSY(3MZ–FE)
	(09904–00050)	No. 4 Claw	STARTER ASSY(3MZ–FE)

Equipment

Ohmmeter	
Sandpaper (#400)	
Service Wire Harness	
Torque wrench	
Vernier caliper	