
3. COMPONENTS

(a) FRONT BUMPER




CAUTION:
The bolts and nuts must be tightened to the torque specification, as they are related to vehicle safety during a collision.

N·m (kgf·cm, ft.·lbf) : Specified torque

B172759

(b) REAR BUMPER




CAUTION:
The bolts and nuts must be tightened to the torque specification, as they are related to vehicle safety during a collision.

N·m (kgf·cm, ft.·lbf) : Specified torque ● Non-reusable part

B172740

(c) INSTRUMENT PANEL




CAUTION:
The bolts and nuts must be tightened to the torque specification, as they are related to vehicle safety during a collision.

N·m (kgf·cm, ft.·lbf) : Specified torque

B168358


(d) INTERIOR TRIM



CAUTION:
The bolts and nuts must be tightened to the torque specification, as they are related to vehicle safety during a collision.

N·m (kgf·cm, ft.·lbf) : Specified torque ● Non-reusable part

B173205





CAUTION:
The bolts and nuts must be tightened to the torque specification, as they are related to vehicle safety during a collision.

N·m (kgf·cm, ft.·lbf) : Specified torque


H

B180002



w/o Rear No. 2 Seat:
NO. 2 DECK BOARD SUB-ASSEMBLY
JACK CARRIER SUPPORT
DECK BOARD ASSEMBLY
JACK CARRIER CUSHION
REAR MAT
NO. 3 DECK BOARD SUB-ASSEMBLY
JACK ASSEMBLY
w/ Tonneau Cover:
JACK CARRIER ASSEMBLY
TONNEAU COVER ASSEMBLY
x 2
DECK SIDE TRIM BOX RH
x 4
REAR FLOOR FINISH PLATE
x 2
x 4
x 2
REAR DECK FLOOR BOX
DECK FLOOR BOARD ASSEMBLY
DECK SIDE TRIM BOX LH
REAR NO. 1 FLOOR BOARD
B178563


w/ Rear No. 2 Seat:
NO. 2 DECK BOARD SUB-ASSEMB LY
DECK BOARD ASSEMBLY
JACK CARRIER SUPPORT
REAR MAT
JACK CARRIER CUSHION
NO. 3 DECK BOARD SUB-ASSEMBLY
JACK ASSEMBLY
w/ Tonneau Cover:
JACK CARRIER ASSEMBLY
TONNEAU COVER ASSEMBLY
x 2
REAR SEAT SIDE COVER RH
REAR FLOOR FINISH PLATE
DECK SIDE TRIM BOX RH
x 2
x 2
REAR SEAT SIDE COVER LH
DECK FLOOR BOARD ASSEMBLY
DECK SIDE TRIM BOX LH
B178565


w/o Rear No. 2 Seat:




w/ Rear No. 2 Seat:



B179722


REAR ASSIST GRIP SUB-ASSEMBLY
ASSIST GRIP COVER
ASSIST GRIP COVER
FRONT ASSIST GRIP SUB-ASSEMBLY
ROOF HEADLINING TRIM CLIP STOPPER
ROOF HEADLINING TRIM CLIP STOPPER
ROOF HEADLINING ASSEMBLY
x 4
NO. 2 ROOM LIGHT ASSEMBLY
NO. 1 ROOM LIGHT ASSEMBLY
VISOR BRACKET COVER
VISOR ASSEMBLY RH
x 2
REAR ASSIST GRIP SUB-ASSEMBLY
FRONT ASSIST GRIP SUB-ASSEMBLY
ROOF CONSOLE BOX ASSEMBLY
VISOR HOLDER
ASSIST GRIP COVER
w/ EC Mirror:
INNER REAR VIEW MIRROR STAY HOLDER COVER
x 2
VISOR ASSEMBLY LH
VISOR BRACKET COVER
VISOR HOLDER
B173214

(e) FRONT SEAT




CAUTION:
The bolts and nuts must be tightened to the torque specification, as they are related to vehicle safety during a collision.

N·m (kgf·cm, ft.·lbf) : Specified torque

B170866

(f) REAR SEAT

for RH side:




CAUTION:
The bolts and nuts must be tightened to the torque specification, as they are related to vehicle safety during a collision.

N·m (kgf·cm, ft.·lbf) : Specified torque

B172889

for LH side:




CAUTION:
The bolts and nuts must be tightened to the torque specification, as they are related to vehicle safety during a collision.

N·m (kgf·cm, ft.·lbf) : Specified torque

B172888

w/ Rear No. 2 Seat:



CAUTION:
The bolts and nuts must be tightened to the torque specification, as they are related to vehicle safety during a collision.

N·m (kgf·cm, ft.·lbf) : Specified torque

B170871