

Power Seat (LHD Driver' s Seat)
Power Seat
(LHD Front Passenger' s Seat)
1
2
3
4
* 1 : w/ Seat Cushion Length Control
* 2 : Before Jul. 2010 Production
* 3 : From Jul. 2010 Production
(BAT)
(BAT)
30A
P/SEAT
30A
P/SEAT
(PS)
1O
1L
1M
(*3)
(*2)
DN3
O39(A), b11(B)
Junction
Connector
N20(A), a11(B)
Junction
Connector
b7
Seat Variable
Cushion Switch LH
b8
Lumbar Support Switch LH
(Power Seat Switch
Assembly LH)
b5
Front Power Seat Switch LH
a5
Front Power Seat Switch RH
Front
Rear
Up
Down
E
CSNF
CSNR
H
R
E2
SLDF
Slide
SLDR
FUP
Front
Vertical
FDWN
RCLF
Reclining
RCLR
LUP
Lifter
LDWN
(*1)
b6
Front Power Seat Cushion
Control Motor Assembly LH
b9
Front Lumbar Support
Forward and Back
Motor Assembly LH
b2
Front Power Seat Slide
Position Motor Assembly LH
b1
Front Power Seat Vertical
Position Motor Assembly LH
b10
Front Power Seat Reclining
Position Motor Assembly LH
b3
Front Power Seat Lift
Position Motor Assembly LH
a2
Front Power Seat Slide
Position Motor Assembly RH
a10
Front Power Seat Reclining
Position Motor Assembly RH
O1
N1