

F RELAY LOCATIONS

: Instrument Panel J/B Assembly	Left Instrument Panel Reinforcement (See Page 21)




Main Body ECU
1H
(from Instrument Panel Wire)
1G
(from Instrument Panel Wire)
30A POWER
(for High Current)
30A P/SEAT
(for High Current)
1I
(from Instrument Panel Wire)

F RELAY LOCATIONS

: Instrument Panel J/B Assembly	Left Instrument Panel Reinforcement (See Page 21)

* 1:Before Jul. 2010 Production
* 2:From Jul. 2010 Production
* 3:30A (*1)
  20A (*2)
* 4:7.5A (*1)
  30A (*2)
* 5:RR FOG (*1)
  P/SEAT (PS) (*2)
* 6:15A (*1)
  10A (*2)
* 7:20A (*1)
  15A (*2)
* 8:10A (*1)
  15A (*2)

