

B43
B28
B30
B39
B32
B42
B34
d2
B27
B29
* 1:Before Jul. 2010 Production
* 2:From Jul. 2010 Production
B40
B31
B37
B36
z12
B44
(*1)
B52
(*2)
B53
z11
B51
B26
B38
B41
B33
B35
d1
C1

B 26 Engine Oil Pressure Switch Assembly
B 27 Throttle Body Assembly
B 28 VSV (ACIS)
B 29 Purge VSV
B 30 Ignition Coil Assembly No.1
B 31 Ignition Coil Assembly No.2
B 32 Ignition Coil Assembly No.3
B 33 Ignition Coil Assembly No.4
B 34 Ignition Coil Assembly No.5
B 35 Ignition Coil Assembly No.6
B 36 Generator Assembly
B 37 Generator Assembly
B 38 Oxygen Sensor (Bank 2 Sensor 2)
B 39 Noise Filter (Ignition Bank 2)
B 40 Camshaft Timing Oil Control Valve (Bank 2 Exhaust Side)
B 41 VVT Sensor (Bank 2 Exhaust Side)
B 42 VVT Sensor (Bank 1 Exhaust Side)
B 43 Camshaft Timing Oil Control Valve (Bank 1 Exhaust Side)
B 44 Cooler Compressor Assembly
B 51 Cooler Compressor Assembly
B 52 Cooler Compressor Assembly
B 53 With Magnet Clutch Compressor Assembly

C 1 Starter Assembly


d 1 Knock Control Sensor (Bank 2)
d 2 Knock Control Sensor (Bank 1)

z 11 Cooling Fan ECU , Cooling Fan Motor
z 12 Cooling Fan ECU , No.2 Cooling Fan Motor

B 26
Gray




B 27
Black




B 28
Gray




B 29
Black




B 30
Black




B 31
Black




B 32
Black




B 33
Black



B 34
Black




B 35
Black




B 36
Black




B 37



B 38
Gray




B 39
Gray




B 40
Black



B 41
Black



B 42
Black




B 43
Black



B 44
Gray




B 51
Gray




B 52
Gray




B 53
Black




C 1




d 1
Gray



d 2
Black



z 11
Gray



z 12
Gray

