

N17
N5
a5
a2
a4
a10
b9
b10
b3
b6
a11
N20
b2
b4
O39
b11
O10
b7
O5
b1
b5
b8


N 5 Side Airbag Squib Circuit RH
N 17 Front Seat Inner Belt Assembly RH
N 20 Junction Connector

O 5 Side Airbag Squib Circuit LH
O 10 Front Seat Inner Belt Assembly LH
O 39 Junction Connector


a 2 Front Power Seat Slide Position Motor Assembly RH
a 4 Seat Heater Control Sub-Assembly RH
a 5 Front Power Seat Switch RH
a 10 Front Power Seat Reclining Position Motor Assembly RH
a 11 Junction Connector

b 1 Front Power Seat Vertical Position Motor Assembly LH
b 2 Front Power Seat Slide Position Motor Assembly LH
b 3 Front Power Seat Lift Position Motor Assembly LH
b 4 Seat Heater Control Sub-Assembly LH
b 5 Front Power Seat Switch LH
b 6 Front Power Seat Cushion Control Motor Assembly LH
b 7 Seat Variable Cushion Switch LH
b 8 Lumbar Support Switch LH (Power Seat Switch Assembly LH)
b 9 Front Lumbar Support Forward and Back Motor Assembly LH
b 10 Front Power Seat Reclining Position Motor Assembly LH
b 11 Junction Connector


N 5
Yellow



N 17
White



N 20
White




O 5
Yellow




O 10
White



O 39
White




a 2
Black




a 4
White




a 5
Black




a 10
Black




a 11
White




b 1
Black



b 2
Black




b 3
White




b 4
White




b 5
Black




b 6
White




b 7
White




b 8
White



b 9
White



b 10
Black



b 11
White

