# SEAT BELT REMINDER SYSTEM

## ■ DESCRIPTION

If a seat belt is not fastened, this system flashes the seat belt reminder light or sounds the buzzer in the combination meter assembly as a reminder.

- When the power source mode is switched to the IG-ON, this system detects the condition of the seat belts based on the signals indicated below.
- The seat belt reminder buzzer for the front passenger can be cancelled.

| Seat | Base Signal | Reminder Method |
|---|---|---|
| Driver | Front Seat Inner Belt Assembly (Driver Side Seat Belt Buckle Switch) (Non-contact Type) | • Buzzer sounds<br>• Reminder light flashes |
| Front Passenger | • Front Seat Inner Belt Assembly (Front Passenger Side Seat Belt Buckle Switch) (Contact Type)<br>• Occupant Detection Sensor | • Buzzer sounds<br>• Reminder light flashes |

**Service Tip**

**Buzzer Reminder Cancel Mode Setting**

Buzzer reminder cancel mode can be set using an intelligent tester. For details, see the HIGHLANDER Repair Manual (Pub. No. RM06K0E).