■ LEG SUPPORT ADJUSTMENT

A leg support adjustment function is provided in order to deal with a wide range of driver heights. The length of the cushion pad front edge can be adjusted.
Adjustment is operated through a link and rod connected to the motor, which extends and contracts the cushion pad.

