
DRIVE SHAFT ASSEMBLY

■DESCRIPTION


- The front drive shaft assembly for all models uses a tripod type CV (Constant Velocity) joints on the differential side, and Rzeppa type CV joints on the wheel side.
- The rear drive shaft assembly for 4WD models uses a tripod type CV (Constant Velocity) joints on the differential side, and Rzeppa type CV joints on the wheel side.

■FRONT DRIVE SHAFT ASSEMBLY

1. 2WD Models




Front Drive Shaft Assembly LH




Front Drive Shaft Assembly RH

06J0CH50C

2. 4WD Models



Front Drive Shaft Assembly LH



Front Drive Shaft Assembly RH

06J0CH51C

CH