
Seat

1. Front Seat

The backs of the front seats are designed so as to ensure legroom for passengers in the 2nd-row seats.




06J0MO27Z

2. 2nd-row Seat

For the 2nd-row seats, a removable center seat is adopted on all models and a remote tilt down function is adopted on some models.


- The removable center seat is adopted to allow for two combinations: a three-person bench seat and two individual captain seats.

▶ Models for China or Models with 5-passenger Seating Capacity for Australia ◀



06J0MO28Z


When used as a three-person bench seat



06J0MO29Z


When used as two individual captain seats

▶ Models with 7-passenger Seating Capacity for Australia ◀



06J0MO36Z

When used as a three-person bench seat




06J0MO37Z


When used as two individual captain seats

Center seat storage procedure

1) Open the console box lid, pull the back lock release strap, and fold the back of the seat forward.




2) Pull the cushion lock release lever to release the lock. Remove the seat, store it in the console box, and close the console box lid.



Remote Tilt Down Function


A remote tilt down function allows the 2nd-row seats to be tilted down with one hand.



06J0MO32Z

3. 3rd-row Seat

Forward folding headrests are adopted, enhancing usability.



06J0MO33Z