
# COWL TOP SIDE PANEL (ASSY)




F28391A

Symbol meaning

| | |
|---|---|
| REMOVAL | : Remove Weld Points |
| INSTALLATION | : Plug Weld |

F28391B

**REMOVAL·INSTALLATION**




F28391

**INSTALLATION POINT**

1 Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
2 Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
3 After welding, apply body sealer to the corresponding parts. (See the paint·coating)
4 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.