
FRONT BODY PILLAR LOWER GUSSET (ASSY)



F28392A


With the cowl top side panel removed.

Symbol meaning

REMOVAL	▲ ▲1 : Remove Weld Points
INSTALLATION	● I : Plug Weld

F28392B

REMOVAL·INSTALLATION



F28392

INSTALLATION POINT

1 *1 is only for installation.
2 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.