

[Body]


Sliding Roof Control ECU
Roof Console Box Assembly
Tire Pressure Warning Antenna and Receiver
Door Control Receiver
Stereo Component Amplifier Assembly
No.1 Glass Hatch Junction Relay
No.2 Glass Hatch Junction Relay
Junction Connector (CAN)
Back Door Motor Unit

[Seat]


Occupant Detection ECU