


■ LAYOUT OF MAIN COMPONENTS



06J0BE62Z




06J0BE06Z


Air Mix Control Servo Motor
(For Driver)
Evaporator Temperature Sensor
Evaporator
Mode Control Servo Motor
Air Inlet Control Servo Motor
Blower Motor
Heater Core
PTC Heater
Air Mix Control Servo Motor
(For Front Passenger)

06J0BE07Z

Heater Control Panel



*: Automatic A/C Only

06J0BE63Z