SRS AIRBAG SYSTEM

■ DESCRIPTION

The SRS (Supplemental Restraint System) has the following equipment:

Item		Equipment
Frontal Collision	SRS Driver (Steering Pad) and Front Passenger Airbags	Standard
	SRS Knee Airbag (For Driver)	Standard
	Seat Belt Pretensioner	Standard
Side/Side Rear Collision	SRS Side Airbags	Standard
	SRS Curtain Shield Airbags (RSCA: Roll Sensing Curtain Shield Airbags)	Standard
Front Passenger Occupant Classification System (4 Occupant Classification Sensors Type)		Standard

- The SRS driver and front passenger airbags are used as supplements to the seat belts to help to reduce the shocks to the head and chest of the driver or front passenger in the event of a frontal impact collision.
- The SRS knee airbag is used as supplements to the seat belt to help to reduce the shock to the knee of the driver in the event of a frontal impact collision.
- The SRS side airbags are used in the event of a side impact collision to help to reduce the shocks to the chest of the driver or front passenger.
- The SRS curtain shield airbags are used in the event of a side or side rear impact collision to help to reduce the shocks to the head of the front passenger, 2nd-row outer passenger, or 3rd-row outer passenger.
- With RSCA, the SRS curtain shield airbags cover the area down to the beltline, there is less chance that passengers will be thrown from the vehicle if it rolls over.

