
GARAGE DOOR OPENER

■ DESCRIPTION

The garage door opener enables a garage door to be opened or closed from inside the vehicle by operating the garage door opener switch that is provided in the roof console box assembly.

- Up to 3 types of transmitter codes can be registered in the garage door opener.
- An LED is provided to enable the operator to verify the operation mode of the garage door opener.
- A rolling code function is used, which changes the transmitter code each time the garage door opener switch is pressed. For details, of procedures of transmitter code registration, refer to the 2008 HIGHLANDER Repair Manual (Pub. No. RM06J0U).

Garage Door Opener Switch



06J0BE30Z