


■ LAYOUT OF MAIN COMPONENTS




07V0BE106Z



07V0BE141Z


Air Mix Control Servo Motor
(For Driver)
Evaporator Temperature Sensor
Evaporator
Mode Control Servo Motor
Air Inlet Control Servo Motor
Blower Motor
Heater Core
Air Mix Control Servo Motor
(For Front Passenger)
07V0BE107Z


Heater Control Panel
Rear Manual A/C
Rear Automatic A/C
Room Temperature Sensor*
Heater Corer
Mode Control Servo Motor
Air Mix Control Servo Motor
Blower Motor
Blower Controller
Evaporator
Evaporator Temperature Sensor
*: Automatic A/C Only
06J0BE63Z