
■WARNING METHOD

The timing chart of the buzzer and details of the warning method are shown below.



*1: If the vehicle speed drops below the setting level for seat belt warning after a buzzer begins to sound, the buzzer will continue to sound. After the vehicle speed exceeds 20 km/h (12.4 mph) again, the buzzer will stop.

*2: Legally mandated buzzer

T1: About 1.8 sec.
T2: About 1.2 sec.
T3: About 13.8 sec.
T4: About 9.6 sec.
T5: About 20 sec.
T6: About 20 sec. or more
T7: About 20 sec. or less
T8: About 9.6 sec. or less