
FUEL LID OPENER

■ DESCRIPTION

An emergency opener has been provided in case the system does not operate due to a discharged battery or other malfunctions.

- The fuel lid opener is controlled by the hybrid vehicle control ECU to prevent fuel vapors from escaping. For details, see page EG-68.

■ SYSTEM DIAGRAM



07V0BE40C