
ENHANCEMENT OF PRODUCT APPEAL

■WASHER NOZZLE

1. Front Washer Nozzle

The washer nozzles are located under the engine hood to ensure good appearance. Spray type nozzles are used. These nozzles can spray windshield washer fluid in a wide range and excellent cleaning performance is achieved.



Spray Pattern

06J0BO08C

Service Tip


Spray type washer nozzles cannot be adjusted because of their structure. Do not attempt to adjust the nozzles as it could damage them.

If adjustment is necessary, adjust the nozzles by replacing them with those selected from three part numbers with different spray angles. For details, see the 2008 HIGHLANDER HYBRID VEHICLE Repair Manual (Pub. No. RM07V0U).

BO

2. Rear Washer Nozzle

Spray type rear washer nozzle is used. This nozzle can spray windshield washer fluid in a wide range and excellent cleaning performance is achieved.



06J0BO09Z