

■ LAYOUT OF MAIN COMPONENTS



07V0HV09Z


Auxiliary Battery
Auxiliary Battery Temperature Sensor
Interlock (for Inverter Cover)
Circuit Breaker Sensor
Inverter with Converter Assembly
• Inverter
• Boost Converter
• DC-DC Converter
• MG ECU
Junction Block
• SMRs
• Current Sensor
• Precharge Resistor
Rear Drive Unit
• MGR
• Resolver
• Temperature Sensor
HV Battery
Hybrid Transaxle
• MG1
• MG2
• Resolvers
• Temperature Sensors
• Power Split Planetary Gear
• Motor Speed Reduction Planetary Gear
Shift Lever Position Sensor
Water Pump
(for Inverter, MG1 and MG2)
Service Plug Grip
• Interlock Switch
Battery Smart Unit

07V0HV10Z