


① : Engine Room R/B Assembly No. 1

○ : Engine Room J/B Assembly No. 1

Front Fender Apron LH


(Before Nov. 2016 Production)

- * 1:80A FAN NO.1
- * 2:30A PBD
- * 3:40A A/C RR
- * 4:30A PTC HTR NO.3
- * 5:30A PTC HTR NO.2
- * 6:50A IG1 NO.4
- * 7:50A PTC HTR NO.1
- * 8:50A HTR
- * 9:140A ALT
- * 10:30A ABS NO.2
- * 11:30A ST
- * 12:40A J/B-B
- * 13:50A ABS NO.1
- * 14:80A EPS
- * 15:FUEL PMP (2GR-FE)
A/F HTR NO.2 (1AR-FE)
- * 16:30A H-LP CLN



① : Engine Room R/B Assembly No. 1	Front Fender Apron LH
○ : Engine Room J/B Assembly No. 1	

Unit A




① : Engine Room R/B Assembly No. 1

○ : Engine Room J/B Assembly No. 1

Front Fender Apron LH

(From Nov. 2016 Production)



① : Engine Room R/B Assembly No. 1	Front Fender Apron LH
○ : Engine Room J/B Assembly No. 1	

Unit B

