



Position of Parts in Engine Compartment (LHD 1AR-FE)




A1	High Pitched Horn Assembly
A2	Low Pitched Horn Assembly
A4	Outside Temperature Sensor (Thermistor Assembly)
A5	Cooling Fan ECU
A8	Front Airbag Sensor LH
A10	Engine Hood Courtesy Switch (Hood Lock Assembly)
A12	Front Airbag Sensor RH
A13	A/C Pressure Sensor
A15	Fog Light Assembly LH
A16	Daytime Running Light Assembly LH
A17	Headlight Assembly LH
A19	Headlight Assembly LH
A20	Headlight Assembly LH
A21	Headlight Assembly LH
A22	Headlight Assembly LH
A23	Fog Light Assembly RH
A24	Daytime Running Light Assembly RH
A25	Headlight Assembly RH
A27	Headlight Assembly RH
A28	Headlight Assembly RH
A29	Headlight Assembly RH
A30	Headlight Assembly RH
A31	Wireless Door Lock Buzzer
A32	Windshield Wiper Motor Assembly
A33	Front Wiper Deicer (Windshield Glass)
A34	Front Speed Sensor LH
A35	Front Speed Sensor RH
A36	Security Horn Assembly
A39	Washer Motor & Pump Assembly
A40	Level Warning Switch Assembly
A41	Headlight Cleaner Control Relay
A42	Headlight Cleaner Motor and Pump Assembly
A43	ECM
A47	Brake Actuator Assembly
A51	Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Sub-Assembly)
A72	No. 1 Ground Junction Connector
A73	No. 2 Ground Junction Connector
A74	No. 3 Ground Junction Connector
A77	No. 2 Junction Connector
A79	Battery
A80	Outside Temperature Sensor (Thermistor Assembly)
A81	Millimeter Wave Radar Sensor Assembly
A82	Headlight Assembly LH
A83	Headlight Assembly LH
A84	Headlight Assembly RH
A85	Headlight Assembly RH
A86	Brake Actuator Assembly
A88	Washer Nozzle Sub-Assembly

Position of Parts in Engine Compartment (LHD 1AR-FE)




90980-10619




90980-10619




90980-11070




90980-12058




90980-12490




90980-11002




90980-12490




90980-10845



82824-60460




90980-12195




90980-11292
(Front Turn Signal Light)




90980-10942
(High)




82824-60460
(Low Halogen Type)




90980-11245
(Low LED Type)



90980-11016
(Headlight Leveling Actuator)




82824-60460




90980-12195




90980-11292
(Front Turn Signal Light)




90980-10942
(High)




82824-60460
(Low Halogen Type)




90980-11245
(Low LED Type)




90980-11016
(Headlight Leveling Actuator)



90980-12572












90980-11599



90980-11348

Position of Parts in Engine Compartment (LHD 1AR-FE)



Position of Parts in Engine Compartment (LHD 1AR-FE)

