


SRS AIRBAG SYSTEM


DESCRIPTION

- The Hilux has adopted a driver SRS (Supplementary Restraint System) airbag and driver and front passenger SRS airbags. The provision of these airbags varies by destination and grade model.
- The SRS airbag helps reduce the shocks to the heads and chests of the driver and front passenger*¹ in the event of severe frontal impact collision as supplements to the seat belts.
- On the gasoline engine model, the airbag sensor assembly includes a fuel cut control that stops the fuel pump when an airbag is deployed.



271BE51

► Wiring Diagram ◀



271BE52

*1: Only for Model with Driver and Passenger SRS Airbags

*2: Only for Australian Model

*3: Except Diesel Engine Model