



G ELECTRICAL WIRING ROUTING

Position of Parts in Instrument Panel



- | | |
|---|---|
| <ul style="list-style-type: none"> 👁 A 9 A/C Amplifier 👁 A 10 A/C Thermistor 👁 A 11 A/C Volume SW 👁 A 12 A/T Shift Lever Illumination 👁 A 13 Accelerator Position Sensor 👁 A 14 Airbag Sensor Assembly Center 👁 A 15 Airbag Squib (Steering Wheel Pad) 👁 A 16 Ashtray Illumination 👁 B 4 Blower Motor 👁 B 5 Blower Resistor 👁 B 6 Blower SW 👁 C 5 Cigarette Lighter 👁 C 6 Cigarette Lighter Illumination 👁 C 7 Clock 👁 C 8 Combination Meter 👁 C 9 Combination Meter 👁 C 10 Combination SW 👁 C 11 Combination SW 👁 C 12 Combination SW 👁 D 1 DLC3 👁 E 5 Engine ECU 👁 E 6 Engine ECU 👁 E 7 Engine ECU 👁 E 8 Engine ECU 👁 F 14 4WD Control ECU 👁 H 5 Hazard Warning Signal SW | <ul style="list-style-type: none"> 👁 I 5 Ignition Key Cylinder Lamp 👁 I 6 Ignition SW 👁 J 2 Junction Connector 👁 J 3 Junction Connector 👁 J 4 Junction Connector 👁 J 5 Junction Connector 👁 J 6 Junction Connector 👁 J 7 Junction Connector 👁 J 8 Junction Connector 👁 J 9 Junction Connector 👁 J 10 Junction Connector 👁 J 11 Junction Connector 👁 J 12 Junction Connector 👁 J 13 Junction Connector 👁 J 14 Junction Connector 👁 J 15 Junction Connector 👁 J 16 Junction Connector 👁 J 17 Junction Connector 👁 J 18 Junction Connector 👁 J 19 Junction Connector 👁 J 20 Junction Connector 👁 J 21 Junction Connector 👁 J 22 Junction Connector 👁 J 23 Junction Connector 👁 J 24 Junction Connector 👁 J 25 Junction Connector 👁 J 26 Junction Connector 👁 J 27 Junction Connector 👁 J 28 Junction Connector 👁 J 29 Junction Connector |
|---|---|

Position of Parts in Instrument Panel



- | | |
|---------------------------------------|-----------------------------------|
| 👁️ K 1 Key Interlock Solenoid | 👁️ T 8 Turbo Motor Driver |
| 👁️ O 1 Outer Mirror SW | 👁️ T 16 Theft Warning ECU |
| 👁️ P 2 Parking Brake SW | 👁️ T 17 Transmission Control ECU |
| 👁️ P 3 Power Point Socket | 👁️ T 18 Transmission Control ECU |
| 👁️ R 1 Radio Receiver Assembly | 👁️ T 19 Transmission Control ECU |
| 👁️ R 2 Radio Receiver Assembly | 👁️ T 20 Transponder Key Amplifier |
| 👁️ R 3 Rear Window Defogger SW | 👁️ T 21 Transponder Key ECU |
| | 👁️ T 22 Turn Signal Flasher |
| 👁️ S 10 Security Indicator Lamp | 👁️ U 1 Unlock Warning SW |
| 👁️ S 11 Shift Lock Control ECU | |
| 👁️ S 12 Short Pin (Theft Warning ECU) | |
| 👁️ S 13 Spiral Cable | |
| 👁️ S 14 Stop Lamp SW | |