


# G ELECTRICAL WIRING ROUTING

## Position of Parts in Body

[Double Cab]



**N** A17 ABS Deceleration Sensor

**N** C13 Center Stop Lamp

**N** D 2 Door Courtesy SW (Driver's Side)

**N** D 3 Door Courtesy SW (Front Passenger's Side)

**N** D 4 Door Courtesy SW (Rear LH)

**N** D 5 Door Courtesy SW (Rear RH)

**N** D 6 Door Lock Assembly (Driver's Side)

**N** D 7 Door Lock Assembly (Front Passenger's Side)

**N** D 8 Door Lock Assembly (Rear LH)

**N** D 9 Door Lock Assembly (Rear RH)

**N** F 12 Front Seat Inner Belt (Driver's Side)

**N** F 13 Fuel Sender Gage

**N** L 1 License Plate Lamp LH

**N** L 2 License Plate Lamp RH

**N** M 1 Map Lamp

**N** O 2 Outer Rear View Mirror (LH)

**N** O 3 Outer Rear View Mirror (RH)

**N** P 4 Power Window Master SW

**N** P 5 Power Window Regulator Motor (Front LH)

**N** P 6 Power Window Regulator Motor (Front RH)

**N** P 7 Power Window Regulator Motor (Rear LH)

**N** P 8 Power Window Regulator Motor (Rear RH)


**N** P 9 Power Window SW (Front Passenger's Side)

**N** P10 Power Window SW (Rear LH)

**N** P11 Power Window SW (Rear RH)

## Position of Parts in Body

### [Double Cab]



- N R 4 Rear Combination Lamp (LH)
- N R 5 Rear Combination Lamp (RH)
- N R 6 Rear Window Defogger
- N R 7 Rear Window Defogger
- N R 8 Room Lamp


- N T 23 Tweeter (LH)
- N T 24 Tweeter (RH)

- N S 15 Speaker (Front Door LH)
- N S 16 Speaker (Front Door RH)
- N S 17 Speaker (Rear Door LH)
- N S 18 Speaker (Rear Door RH)
- N S 21 Speed Sensor (Rear LH)
- N S 22 Speed Sensor (Rear RH)

# G ELECTRICAL WIRING ROUTING

## Position of Parts in Body

[Extra Cab]



N A17 ABS Deceleration Sensor

N C13 Center Stop Lamp

N D 2 Door Courtesy SW (Driver's Side)

N D 3 Door Courtesy SW (Front Passenger's Side)

N D 6 Door Lock Assembly (Driver's Side)

N D 7 Door Lock Assembly (Front Passenger's Side)

N F 12 Front Seat Inner Belt (Driver's Side)

N F 13 Fuel Sender Gage

N L 1 License Plate Lamp LH

N L 2 License Plate Lamp RH

N M 1 Map Lamp

N O 2 Outer Rear View Mirror (LH)

N O 3 Outer Rear View Mirror (RH)

N P 4 Power Window Master SW


N P 5 Power Window Regulator Motor (Front LH)

N P 6 Power Window Regulator Motor (Front RH)

N P 9 Power Window SW (Front Passenger's Side)

## Position of Parts in Body

**[Extra Cab]**



- N R 4 Rear Combination Lamp (LH)
- N R 5 Rear Combination Lamp (RH)
- N R 6 Rear Window Defogger
- N R 7 Rear Window Defogger
- N R 8 Room Lamp


- N T 23 Tweeter (LH)
- N T 24 Tweeter (RH)

- N S 15 Speaker (Front Door LH)
- N S 16 Speaker (Front Door RH)
- N S 19 Speaker (Rear LH)
- N S 20 Speaker (Rear RH)
- N S 21 Speed Sensor (Rear LH)
- N S 22 Speed Sensor (Rear RH)

# G ELECTRICAL WIRING ROUTING

## Position of Parts in Body

[Single Cab]



**N** A17 ABS Deceleration Sensor

**N** C13 Center Stop Lamp

**N** D 2 Door Courtesy SW (Driver's Side)

**N** D 3 Door Courtesy SW (Front Passenger's Side)

**N** D 6 Door Lock Assembly (Driver's Side)

**N** D 7 Door Lock Assembly (Front Passenger's Side)

**N** F 12 Front Seat Inner Belt (Driver's Side)

**N** F 13 Fuel Sender Gage

**N** L 1 License Plate Lamp LH

**N** L 2 License Plate Lamp RH

**N** O 2 Outer Rear View Mirror (LH)

**N** O 3 Outer Rear View Mirror (RH)

**N** P 4 Power Window Master SW


**N** P 5 Power Window Regulator Motor (Front LH)

**N** P 6 Power Window Regulator Motor (Front RH)

**N** P 9 Power Window SW (Front Passenger's Side)

Position of Parts in Body

[Single Cab]



- N** R 4 Rear Combination Lamp (LH)
- N** R 5 Rear Combination Lamp (RH)
- N** R 8 Room Lamp

- N** S15 Speaker (Front Door LH)
- N** S16 Speaker (Front Door RH)
- N** S21 Speed Sensor (Rear LH)
- N** S22 Speed Sensor (Rear RH)