

M OVERALL ELECTRICAL WIRING DIAGRAM




4WD (1GR–FE, 2TR–FE)
* 1 : 1GR–FE
* 2 : 2TR–FE
* 6 : w/ Rear Diff. Lock
5
6
7
8
Engine ECU <5–13>
Skid Control ECU with Actuator <20–6>
4WD Control ECU (Rear Diff. Lock) <29–3>
Engine ECU <4–14>
(*2)
G–W
(w/ ABS)
(*6)
6 ID1
6 EA1
10 ID1
(*2 w/ ABS)
(*1 w/ ABS)
(*2 *6)
(*1 *6)
(*1)
8 B
7 B
12 A
11 A
J33(A), J34(B) Junction Connector
11
12
5
4
J36 Junction Connector
G–W (*1 w/ ABS)
G–W(*1)
1
2
T 4 Transfer Indicator SW (L4 Position)
A
B
W–B
(*1)
(*2)