■ DAYTIME RUNNING LIGHT SYSTEM

- The daytime running light system is available as optional equipment on the LHD models for Europe.
- This system is designed to automatically activate the low beams of the headlights, position lights, license plate lights, and taillights during the daytime to keep the car highly visible to other vehicles. This system is controlled by the daytime running light relay.
- This system is enabled when the conditions given below are met:
  - Ignition switch is ON.
  - Alternator L terminal signal input is on (engine running condition).
  - Light control switch is off.

▶ System Diagram ◀

