

F RELAY LOCATIONS

Junction Connector (CAN)	LHD : Instrument Panel Brace LH (See Page 21)
	RHD : Instrument Panel Brace RH (See Page 21)

