















- F 2 Fog Lamp (Front LH)
- F 3 Fog Lamp (Front RH)
- F 4 Fuel Filter Warning SW
- F 5 Fuel Injector (No.1)
- F 6 Fuel Injector (No.2)
- F 7 Fuel Injector (No.3)
- F 8 Fuel Injector (No.4)
- F 9 Fuel Pressure Sensor
- F 10 Fuel Sedimentary Level Warning SW
- F 11 Fuel Temp. Sensor
- F 31 Fuel Injector (No.1)
- F 32 Fuel Injector (No.2)
- F 33 Fuel Injector (No.3)
- F 34 Fuel Injector (No.4)
- F 44 Fog Lamp (Front RH)
- F 45 Fog Lamp (Front LH)

- G 1 Glow Plug
- G 2 Glow Plug Controller
- G 3 Glow Plug Controller
- G 4 Glow Plug Controller
- G 5 Glow Plug Controller
- G 6 Glow Plug Assembly











Position of Parts in Engine Compartment <LHD 1KD-FTV, 2KD-FTV>




(Europe 1KD-FTV From Aug. 2006 Production, Europe 2KD-FTV From Aug. 2009 Production, Australia From Aug. 2006 Production, South Africa From Aug. 2010 Production, Middle East From Aug. 2010 Production)



(Europe 1KD-FTV Before Aug. 2006 Production, Europe 2KD-FTV Before Aug. 2009 Production, Australia Before Aug. 2006 Production, South Africa Before Aug. 2010 Production, Middle East Before Aug. 2010 Production)



G 5
Black



G 6
Black

