





- * 1:w/ PTC Heater Cold Area Spec.
w/ Air Conditioner
- * 12:w/ VSC
- * 13:w/o VSC
- * 22:1KD-FTV w/ DPF,
2KD-FTV w/ DPF
- * 23:1KD-FTV M/T w/ DPF,
2KD-FTV M/T w/ DPF

- * 24:Except *23
- * 25:Except *22
- * 26:Before Aug. 2012 Production
- * 27:From Aug. 2012 Production

- A 1 A/C Compressor
- A 2 A/T Fluid Temp. Sensor
- A 3 ADD Actuator
- A 4 Air Flow Meter
- A 5 Airbag Sensor (Front LH)
- A 6 Airbag Sensor (Front RH)
- A 7 Alternator
- A 8 Alternator
- A 26 Ambient Temp. Sensor
- A 31 A/C Pressure Sensor
- A 32 A/C Magnetic Valve
- A 39 Ambient Temp. Sensor
- A 40 Air Flow Meter
- A 41 Air Fuel Ratio Sensor
- A 50 Airbag Sensor (Front LH)
- A 51 Airbag Sensor (Front RH)

- B 1 Back-Up Lamp SW
- B 2 Brake Fluid Level Warning SW
- B 3 Brake Vacuum Warning SW
- B 9 Brake Vacuum Warning SW






Position of Parts in Engine Compartment <RHD 1KD-FTV, 2KD-FTV>




(1KD-FTV, 2KD-FTV)




(2TR-FE)




(1GR-FE)




(1TR-FE, 2TR-FE, 1KD-FTV, 2KD-FTV)









(5L-E)




(Except 5L-E)



(5L-E)



(2TR-FE)



(Except 2TR-FE)

