


- * 8:Europe From Aug. 2006 Production,
Australia From Aug. 2006 Production
- * 9:Except *8
- * 22:1KD-FTV w/ DPF, 2KD-FTV w/ DPF









- C 1 Camshaft Position Sensor
- C 2 Clearance Lamp (Front LH)
- C 3 Clearance Lamp (Front RH)
- C 4 Crankshaft Position Sensor
- C 28 Clearance Lamp (Front RH)
- C 29 Clearance Lamp (Front LH)










- D 19 Differential Pressure Sensor

- E 1 ECT Solenoid
- E 2 EGR Valve Position Sensor
- E 3 Engine Hood Courtesy SW
- E 4 Engine Oil Pressure Sensor
- E 18 Engine Oil Level Sensor
- E 28 Electric EGR Control Valve Assembly
- E 29 EGR Valve Assembly
- E 32 Exhaust Fuel Addition Injector Assembly
- E 33 Engine Hood Courtesy SW (Interior Light)

Position of Parts in Engine Compartment <RHD 1KD-FTV, 2KD-FTV>



(1TR-FE, 2TR-FE, 1KD-FTV, 2KD-FTV)



(1KD-FTV, 2KD-FTV Europe From Aug. 2006 Production)

(2KD-FTV Except Europe From Aug. 2006 Production)

