





























K	1	Key Interlock Solenoid
L	3	Light Control Rheostat
M	2	Magnet Clutch Relay
M	7	Magnet Clutch Relay
N	4	No. 1 Stereo Jack Adapter Assembly
N	9	Navigation Receiver Assembly
N	10	Navigation Receiver Assembly
N	11	Navigation Receiver Assembly
N	12	Navigation Receiver Assembly
N	13	Navigation Receiver Assembly
N	14	No. 1 Stereo Jack Adapter Assembly
O	1	Outer Mirror SW
O	8	Option Connector (Daytime Running Light ECU)
P	2	Parking Brake SW
P	3	Power Outlet Socket
P	13	Passenger Seat Belt Warning Lamp
P	14	Power Heater SW
P	16	PTC Heater
P	17	PTC Heater
P	18	PTC Heater Relay (No.1)
P	19	PTC Heater Relay (No.2)
P	21	Power Heater SW
R	1	Radio Receiver Assembly
R	2	Radio Receiver Assembly
R	3	Rear Window Defogger SW
R	9	Rear Fog Lamp Relay
R	11	Resistor (L4 Position)
R	12	Radio Receiver Assembly
R	17	Radio Receiver Assembly
R	18	Radio & Display Receiver Assembly
R	19	Rear Fog Light Switch
R	20	Radio Receiver Assembly
R	21	Radio & Display Receiver Assembly
R	22	Radio & Display Receiver Assembly
R	23	Radio & Display Receiver Assembly
R	24	Radio & Display Receiver Assembly
R	28	Radio & Display Receiver Assembly
R	29	Rear Fog Lamp Relay
R	30	Radio & Display Receiver Assembly

Position of Parts in Instrument Panel <RHD>



Position of Parts in Instrument Panel <RHD>

