
BLOCKING SYSTEM


■ DESCRIPTION

- The blocking system can be used to secure a stolen vehicle as soon as possible. The system consists of a localization function, which reports the present location of the vehicle, and a blocking function, which prevents the vehicle's engine from being started. The combined use of the two functions actively contributes to quickly securing the stolen vehicle.
- The blocking system service is provided by a service provider which must be contracted by the user. In addition, when contracted with the service provider, the user can select a contract with blocking function only or with both blocking function and localization function.
- The blocking system is composed of a DCM (Data Communication Module) with a built-in auxiliary battery, a GPS (Global Positioning System) antenna and a telephone antenna.
- The blocking system is provided as standard equipment on models for Brazil.

▶ System Image ◀



Localization Function 00LBE34I



Blocking Function 00LBE35I